

Thermal decomposition behavior of the tobacco material used in a heated tobacco product

Markus Nordlund, Ph.D.

PMI Research & Development, Philip Morris Products S.A., Neuchâtel, Switzerland

Outline

- Introduction
- Objective
- Method
- Results
- Conclusions
- Future work



Introduction: Heat-not-burn versus combustion





LIP MORRIS INTERNATION

Introduction: Heat-not-burn versus combustion





McGrath, T. E. et al. (2007) Formation of Polycyclic Aromatic Hydrocarbons from Tobacco: the "Link" between Low Temperature Residual Solid and PAH Formation, Food and Chemical Toxicology, 45, 6, 1039-1050

Introduction: Heat-not-burn versus combustion





Examples of smoke aerosols

Non-smoke aerosols



Examples of non-smoke aerosols



Introduction: Tobacco Heating System (THS) 2.2

• THS 2.2 heats tobacco to temperatures below 350 °C to avoid combustion and to produce a nicotine-containing, non-smoke aerosol



Introduction: Tobacco Heating System (THS) 2.2

Temperature in THS 2.2 during use under



www.pmiscience.com

R = Radial position of thermocouple relative to the surface of the heater HCI = 55 mL puff, 2 s puff duration, 30 s puff interval

Objective

To better **understand** the underlying **thermochemical processes** occurring in the THS 2.2 tobacco material **when heated** in the Holder, we aimed to:

- Determine the onset temperature for combustion of the tobacco material
- Establish evaporation and thermal degradation characteristics of the tobacco material and to relate them to main tobacco material constituents



Method

- Thermogravimetry Differential scanning calorimetry measurements of THS 2.2 tobacco material using a LABSYS evo simultaneous thermal analysis
- Nitrogen and air atmospheres
- Temperature range: 25 °C 550 °C
- Two constant heating rates (5, 10 K/min)
- Four replicates
- Measurements carried out by SETARAM Instrumentation, France



Results: THS 2.2 tobacco mass and heat evolution



Results: THS 2.2 tobacco mass and heat evolution



Results: THS 2.2 tobacco mass and heat evolution

Influence of heating rate on mass and heat evolution



5 K/min heating rate

10 K/min heating rate

Results: identification of mass loss rate peaks



Conclusions

- Thermal degradation of the THS 2.2 tobacco material below 400 °C involves a combination of endothermic and weakly exothermic processes that can be attributed to evaporation or degradation of individual constituents in the tobacco material
- Combustion of the THS 2.2 tobacco material occurred above 400 °C, only in the presence of oxygen (evidenced by a strong exothermic peak, mass loss and ash formation)
- Thermal degradation of THS 2.2 tobacco below 400 °C was largely unaffected by the presence of externally supplied oxygen, with only a slight shift in mass loss towards lower temperatures and a change from a mostly endothermic to a weakly exothermic degradation chemistry
- Water, glycerol, and nicotine evaporation accounts for the majority of the mass loss from the tobacco material below 200 °C
- The **thermal degradation chemistry** of the tobacco material in **THS 2.2** during use under the HCI puffing regimen **shows a net endothermic behavior and absence of combustion**



Extensive characterization of the thermochemical decomposition kinetics of the THS 2.2 tobacco material and its individual components, **with the aim of developing a detailed thermochemical degradation kinetics model for the tobacco material**, predictive of mass and heat evolution as well as volatilization and potential formation of degradation products





Thank you for your attention!

The research described in this presentation was funded by Philip Morris International